

19283
AIRPORT DIAGRAM

BALTIMORE/WASHINGTON INTL THURGOOD MARSHALL (BWI)
 AL-804 (FAA)
 BALTIMORE, MARYLAND

324 A

D-ATIS
 115.1 127.8
 BALTIMORE TOWER
 119.4 257.8
 GND CON
 121.9
 CLNC DEL
 118.05
 CPDLC

D


RWY 10-28
 PCN 105 F/A/W/T
 S-80, D-220, 2D-1020, 2D/2D2-1340
 RWY 15L-33R
 PCN 15 F/A/W/T
 S-30, D-45
 RWY 15R-33L
 PCN 70 F/A/W/T
 S-80, D-220, 2D-675, 2D/2D2-890

JANUARY 2015
 ANNUAL RATE OF CHANGE
 0.0° W



NE-3, 07 NOV 2019 to 05 DEC 2019

NE-3, 07 NOV 2019 to 05 DEC 2019



ASDE-X in use. Operate transponders with altitude reporting mode and ADS-B (if equipped) enabled on all airport surfaces.

Runway Status Lights in operation.

**CAUTION: BE ALERT TO RUNWAY CROSSING CLEARANCES.
 READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS IS REQUIRED.**



19283
AIRPORT DIAGRAM

BALTIMORE, MARYLAND
 BALTIMORE/WASHINGTON INTL THURGOOD MARSHALL (BWI)